



SCIENCE. SERVICE. SAFETY.

# Cure Schedules for BlazeMaster® CPVC

BlazeMaster® CPVC pipe and fittings are lightweight, flexible and join together using a quick, one-step solvent cement process. For a successful installation, follow manufacturer's recommended cure times for pressure, pipe size and temperature. The following cure schedules assume that the pipe and fittings are dry. If water is present, cure times will increase.

## **Cure Schedules for New Systems**

### 225 PSI (1552 KPA) Test Pressure (Maximum)

Ambient Temperature During Cure Period (Use this table for all cut-ins)

Pipe Size	60°F to 120°F (16°C to 49°C)	40°F to 59°F (4°C to 15°C)	0°F to 39°F (-18°C to 4°C)
3/4" (20 mm)	1 hr.	4 hrs.	48 hrs.
1" (25 mm)	1 1/2 hrs.	4 hrs.	48 hrs.
1 1/4" and 1 1/2" (32 and 40 mm)	3 hrs.	32 hrs.	10 days
2" (50 mm)	8 hrs.	48 hrs.	Note 1
2 1/2" and 3" (65 and 80 mm)	24 hrs.	96 hrs.	Note 1

#### 200 PSI (1379 KPA) Test Pressure (Maximum)

**Ambient Temperature During Cure Period** 

Pipe Size	60°F to 120°F (16°C to 49°C)	40°F to 59°F (4°C to 15°C)	0°F to 39°F (-18°C to 4°C)
3/4" (20 mm)	45 mins.	1 1/2 hrs.	24 hrs.
1" (25 mm)	45 mins.	1 1/2 hrs.	24 hrs.
1 1/4" and 1 1/2" (32 and 40 mm)	1 1/2 hrs.	16 hrs.	120 hrs.
2" (50 mm)	6 hrs.	36 hrs.	Note 1
2 1/2" and 3" (65 and 80 mm)	8 hrs.	72 hrs.	Note 1

Note 1: For these sizes, the solvent cement can be applied at temperatures below  $40^{\circ}F$  ( $4^{\circ}C$ ). However, the sprinkler system temperature must be raised to a temperature of  $40^{\circ}F$  ( $4^{\circ}C$ ) or above and allowed to cure per the above recommendations prior to pressure testing.

Follow manufacturer's instructions on pressure testing. Fill lines slowly and bleed the air from the system prior to pressure testing.

#### 100 PSI (690 KPA) Test Pressure (Maximum)

Ambient Temperature During Cure Period

Pipe Size	60°F to 120°F (16°C to 49°C)	40°F to 59°F (4°C to 15°C)	0°F to 39°F (-18°C to 4°C)
3/4" (20 mm)	15 mins.	15 mins.	30 mins.
1" (25 mm)	15 mins.	30 mins.	30 mins.
1 1/4" (32 mm)	15 mins.	30 mins.	2 hrs.

# **Cure Schedules for Existing Systems**

#### **Cut-ins: Minimum Cure Prior to Pressure Testing**

Ambient Temperature During Cure Period

Pipe Size	60°F to 120°F (16°C to 49°C)	40°F to 59°F (4°C to 15°C)	0°F to 39°F (-18°C to 4°C)
3/4" (20 mm)	1 hr.	4 hrs.	48 hrs.
1" (25 mm)	1 1/2 hrs.	4 hrs.	48 hrs.
1 1/4" and 1 1/2" (32 and 40 mm)	3 hrs.	32 hrs.	10 days
2" (50 mm)	8 hrs.	48 hrs.	Note 2
2 1/2" and 3" (65 and 80 mm)	24 hrs.	96 hrs.	Note 2

Note 2: Solvent cement can be applied at temperatures below 40°F (4°C) for pipe 2 inches in size and larger. However, the temperature of the system must be raised to 40°F (4°C) or higher and allowed to cure per the above recommendations prior to pressure testing. When bringing cement, pipe or fittings in from the outside, be sure they are brought up to room temperature before using the 60°F (16°C) to 120°F (49°C) cure schedule.





The Lubrizol Corporation, a Berkshire Hathaway company 9911 Brecksville Road ■ Cleveland, Ohio 44141-3201 USA 216.447.5330 ■ blazemaster@lubrizol.com

The information contained herein is reliable based on current information but the advertiser makes no representations, guarantees or warranties, express or implied, including any implied warranties of merchantability or fitness for a particular purpose, or regarding the completeness, accuracy, or timeliness of any information. Always consult your pipe and/or fitting manufacturer for current recommendations.

